

Accessori a richiesta

Set bit, 23 pezzi

Art.-Nr.: 4258073
EAN-Code: 4006825573268
Einhell Grey



Set punte e bit, 70 pezzi

Art.-Nr.: 4258085
EAN-Code: 4006825563610
Einhell Grey



18V 5,2 Ah Power-X-Change
Batteria
Art.-Nr.: 4511357
EAN-Code: 4006825598865
Einhell Accessory



18V Power-X-Change
PXC caricabatteria
Art.-Nr.: 4512011
EAN-Code: 4006825587029
Einhell Accessory



18V Starter-Kit Power-X-Change
PXC-Starter-Kit
Art.-Nr.: 4512021
EAN-Code: 4006825601350
Einhell Accessory



18V 1,5 Ah Power-X-Change
Batteria
Art.-Nr.: 4511340
EAN-Code: 4006825590586
Einhell Accessory



18V 3,0 Ah Power-X-Change
Batteria
Art.-Nr.: 4511341
EAN-Code: 4006825590593
Einhell Accessory